

# AIR VALVE EXTRAS

## SPECIFICATIONS:

- A core without a spring provides a reliable sealing mechanism for air valves.
- A brass coupling connects the air valve cap thread to a 1/8" NPT fitting, ensuring a secure and efficient connection
- Durable plastic and sturdy metal caps protect air valves from dust, debris, and harsh environments.



No Lead

DIMENSIONS			
Part No.	L in.	W & H in.	Description
SVCS	1.29	0.20	Core with No Spring
SVAC18	1.01	0.57	Brass Coupling - Air Valve Cap Thread to 1/8" NPT
SVCP	0.49	0.42	Plastic Cap for Air Valves
SVCM	0.47	0.36	Metal Cap for Air Valves

